

Proper Copper Draught Excluder Installation Instructions

Step-By-Step Guide

Step 1: Ensure that the door is correctly fitted. The gap between the door and frame should exceed 2mm.

Step 2: Remove paint runs, filler nails etc., from the surface to which the strip is to be fitted.

Step 3: Cut separate lengths for each jamb and the head.

Step 4: Nail the copper strips in position using the indents in the strip.

Step 5: The strips may be sprung so that they make contact with the door upon closing. Find a ballpoint pen or similar shaped tool. Run the tool along the springing line which is visible adjacent to the pin line. You can adjust the pressure exerted in order to achieve the desired degree of lift.

Product Options

The Proper Copper Draught Excluder comes in two widths:

- **25mm** for standard doors;
- **14mm** for casement windows, french doors and windows.

