

## Installation Guide Ecoflap

The Ecoflap can be fitted simply with screws or without;

### Fitting With Screws

Firstly you will need to remove your existing draught proofing system and measure the hole. You will need to mark the centre of top edge.

Take your Ecoflap and locate the “lining up” lip at the back, Rest the lip onto and inside the lower edge of the letter box hole.

Bring the central screw hole in line with your centre mark. Tape along the top to hold in place. The bottom is already supported by the locator lip.

There are six screw holes. Screw into the door. NB Screws not provided, due to varying depth of door and materials. Depth of screws recommended are 3.5 mm x 12 - 15 mm countersink.

Finish by fitting the caps for aesthetic appearance.

### Fitting Without Screws

Firstly you will need to remove your existing draught proofing system and measure the hole. You will need to mark the centre of top edge.

Take your Ecoflap and fit the screw caps then turn it over and apply kitchen or bathroom sealant (available from hardware stores) around the flange.

Take your Ecoflap and locate the “lining up” lip at the back, Rest the lip onto and inside the lower edge of the letter box hole.

Bring the central screw hole in line with your centre mark. Tape along the top to hold in place. The bottom is already supported by the locator lip.

Tape across the top to hold in place until set.