



Disposable Shower Filter Install Instructions

Important:

for best results flow should not exceed 2.5 GPM at 60 psi. If necessary, replace your existing showerhead with a water saving head with a flow rate of 2.5 GPM or less.

Instllation Procedures

1. remove existing showerhead
2. attach existing showerhead to new shower filter.
3. Insall new filter and head to shower pipe.
4. Rotate date indicator to show date of installation.

Note:

under normal conditions replace filter on an annual basis.

Caution:

hand tighten to avoid cross threading when connecting metal threads to your dial a date shower filter.

For advice call: 020 8539 4707